Contents

Preface 1

Purpose and Scope 2
Audience 2
What's New in this Release 2
Release 1.2 2
Release 1.1.2 3
Release 1.1 4
Organization 5
Notational Conventions 6
Related Documents 6
Getting Help 7
Contacting Customer Support 7
Customer Support Contact Details 7
Field Replaceable Components 8

Safety and Regulatory Notices 11

Important Safety Instructions 12
General 12
Installation of Wiring 12
Fuse and Component Replacement 13
Notices 13
Symbols 14
Installation Summary 15
Regulatory Notices 16
Notice to Canadian Customers 16
Federal Communications Commission (FCC) Notice 16

Introduction 17

Product Overview 18
SIP 18

Call Model 19
Service Logic Execution Environment 20
Call Accounting 23
High Availability Setup 24
Service Features 25
Network Services 25
Voice over IP Virtual Private Network (VoIP VPN) 25
Intelligent Routing Service (IRS) 29
Local Number Portability 32
SS8 Service Management System 32
Intelligent Services Architecture 33
Switch Platform 35
System Components 35
Chassis 38

Installing the Hardware 41

Overview 42
Safety Requirements 43
Safety with Electricity 43
Preventing Electrostatic Discharge 43
General Site Requirements 44
Dimensions 44
Weight 44
Temperature and Heat Dissipation 44
Power Requirements 45
Cabling Precautions 45
Required Tools and Equipment 45
Unpacking and Inspecting the Chassis 46
Reporting Damage and Discrepancies 47
Installing the Chassis 48
Connecting to a Power Source 50
Power Supply Units 50
Power Inputs 51
Power Switches 52
Connecting to a DC Power Source 53
Connecting to an AC Power Source 54
Verifying the Installation 56
System Cards 57
Card Slot Conventions 58
System Controller Card (Sun CP1500-440) 59
System Controller Transition Card (Sun XCP-TRN) 60

Application Processing Card (CES RIOC 4065) 61
Inserting and Removing the System Cards 62
Alarm Card 63
Network Cabling 64
Connecting a Serial Cable to the APC 65
Connecting an Ethernet Cable to the APC 65
Connecting a Serial Cable to the System Controller 66
Connecting an Ethernet Cable to the System Controller 66

Commissioning the System 67

HA versus Non-HA 68
High Availability System 68
Non-High Availability System 70
Initial Startup 72
Configuring the System Controller Card 73
Installing the Software and Configuring the Card Settings 74
Configuring the Time Zone 79
Synchronizing the Network Time 80
Rebooting the System Controller Card 80
Rebooting a Switch in an HA Configuration 81
Configuring the Application Processing Card 82
Maintaining the Cards 86

Provisioning the System 87

Overview 88
Base Applications 90
High Availability Node Management (HANM) 90
Updating the HANM Configuration File 90
HANM Configuration File Parameters 92
Applications 98
Allocating Memory Resources to the APCs 99
Updating the System Services Interface (SSI) Memory Configuration File 99
Updating the Memory Pools Configuration File 100
Real-time Relational Database (RTRDB) 101
Preventing Port Number Conflicts 101
Journaling Data in a High Availability Setup 102
Call Accounting 104
Billing System for Intra-Domain Calls 104
Open Settlement Protocol (OSP) for Inter-Domain Calls 107
Configuring Billing and OSP 110

Updating the Billing Configuration File 111
Billing Configuration File Parameters 112
Configuring the Open Settlement Protocol Client 117
Updating the OSP Billing Configuration File 118
OSP Billing Configuration File Parameters 119
Updating the OSP Configuration file 120
Enrolling the OSP Client 121
Services Applications 123
Service Logic Execution Environment 123
Updating the SLEE Configuration File 123
SLEE Configuration File Parameters 125
Service Management System Proxy 127
Updating the SMS Proxy Configuration File 127
Intelligent Routing Service 128
Updating the IRS Configuration File 128
IRS Configuration File Parameters 129
Session Initiation Protocol (SIP) 130
Overview of SIP 130
Updating the SIP Configuration File 135
SIP Configuration File Parameters 136
SIP Authentication 141
Configuring the SIP Authentication Default Realm 143
Configuring SIP Authentication Users 144
Exempting Endpoints from SIP Authentication 149
Routing Protocols and Applications 151
Overview of Routing Functionality 151
Routing Example 152
Typical Setup 153
Call Routing Engine (CRE) 154
Updating the CRE Configuration File 160
CRE Configuration File Parameters 161
Updating the CRE Policy File 164
CRE Policy File Syntax 164
Sample CRE Policies 167
Telephony Routing over IP 169
TRIP Support for Gateway Statuses 170
Updating the TRIP Configuration File 174
TRIP Configuration File Parameters 175
Updating the TRIP Policy File 180
TRIP Policy File Syntax 180
Sample TRIP Policies 185

Maintenance 189

Card-Level Commands 190
- Using Telnet to Access the System Controller 191
- System Controller Commands 192
- Using rlogin to Access the Application Processing Card 193
- Application Processing Card Commands 195

Rebooting the System 197

System Controller Directory Structure 198

Managing the Software Load 202
- Determining the Software Load Number 203
- Downloading Software to the System 204
- Backing up and Restoring the Software Load 205
- Installing a New Software Load 207

SNMP Management 210
- Configuring the Interface to a Management System 210
  - Configuring the Switch to Send Traps 211
  - Configuring the Network Management System 212
  - Loading MIBs into the Network Management System 212
  - Configuring SNMP Security 213
- MIBs 213
- TRAPs 215

Log Files 221
- Viewing Messages in Real Time 221
- Viewing and Saving the Message Logs 222
- Enabling Message Traces 224

Initializing the Database 225

Troubleshooting 226
- Configuration Errors 226

Call Detail Record Formats 229

SS8 CDR Field Formats for SIP Calls 230

SS8 CDR Field Formats for H.323 Calls 238

SS8 CDR Field Formats for IWG Calls 240

SS8 CDR Field Formats for LNP Queries 245

MIND-iPhonEX CDR Field Formats for SIP Calls 247

Glossary 251

Index 259